



ThermoPol Set



Ref.No 313203

Polieren von thermoplastischen Kunststoffen
am Poliermotor

Polishing of thermoplastics on the
polishing lathe

Polissage des thermoplastiques sur le
moteur de polissage



Politur am Poliermotor

on the polishing lathe

sur le moteur de polissage

1

Vorpolitur

pre-polishing

pré polissage



Einlagebürste
4280

+



Polistar
Lintygrau 90g

→



2

Glanzpolitur

shine polishing

poli brillant



COSIMA Soft
Polierschwabbel
869 100/14

+



Polistar
Creme 90g

→



3

Hochglanzpolitur

high shine polishing

lustrage



MIRA
Polierschwabbel
868 4''x50 H

+



Polistar Pro
Rosa 150g

→



Info

4280 = Ø 80mm = 1.400 rpm
869 100/14 = Ø 100mm = 1.400 rpm
868 4''x50 H = Ø 100mm = 1.400 rpm

ThermoPol Set

Inhalt/contents/contenu

2x 4280, 1x Polistar Lintygrau 90g, 1x 869 100/14, 1x Polistar Creme 90g,
1x 868 4''x50 H, 1x Polistar Pro Rosa 150g